

HIOKI 9219 Connection Cord




Connect with the 9695-02/-03, Output BNC terminal

Features

16. A choice of optional clamp-on sensors

- 9694 (5A rms)
- 9660 (100A rms)
- 9661 (500A rms)
- 9669 (1000A rms)
- 9667 Flexible (5000A rms)



Features

17. Handy Wiring Adapters

Model 9264-01 (3-phase 3-wire)

Model 9264-02 (3-phase 4-wire)

