
SQ 96



Data Sheet
Electronic Synchroscope



Application

The Electronic Synchroscope is designed to provide an illuminated indication of actual phase difference between the BUS Voltage(reference voltage) & the GENERATOR Voltage(incoming voltage)

It denotes the actual frequency difference corresponding to the inverse of time taken for one rotation of the

illuminated vector spot. When two alternators are

paralleled, it is necessary that, 1)Frequency must be equal. 2)Phase must be same.

Sychroscope is,hence used to indicate the Phase & Frequency difference between two AC alternators, which are to be paralleled.

Features

- Rotating LED indication of Frequency & Phase difference of two supplies
- Glass filled polycarbonate housing (UL 94-V-0)
- Easy installation with swivel screws.

Description

The rotation of the vector spot is with reference to the bus

voltage. If the vector spot LED turns clockwise, it indicates the GENERATOR frequency is greater than the BUS frequency. It means the speed of the generator must be reduced by the operator.

If the spot LED turns anticlockwise, the GENERATOR frequency is less than BUS frequency. In this case speed of the generator must be increased.

If 'T' is the time taken for one rotation, the frequency difference can be calculated as 1/T = A f

Example: Let the bus frequency be 50 Hz.The vector spot takes 10 Sec. for one rotation, clockwise.

1/10 = 0.1 Hz.

The frequency difference = 0.1Hz. Hence we can infer that GENERATOR frequency is 50.1 Hz.

If the Frequency & Phase of BUS signal matches with those of GENERATOR signal, the two green led's at 12 o'clock position glow.

If the Frequency matches & Phase does not, then one red led corresponding to the phase difference will glow.

Favorable condition for" Switching in" the Generator:


1.Ensure that the frequency difference between two inputs is within the requirements of user as follows:

Measure time taken for 1 complete rotation of the vector spot in SECOND(T).

The frequency difference will be Af = 1/T(Hz)

2. Provided the frequency difference is within acceptable limits, wait till the SYNC mark LED s(two green LED s at 12 o'clock position)glow. At this instant, it is safe to CONNECT the GENERATOR to BUS.

Functional Principle



The Bus & Gen inputs are fed to the Frequency & Phase detection network. The output duty cycle of the network corresponds to the frequency difference between Bus & Generator Voltage. The detector network also determines the actual phase difference.

Specifications

Moulded square case suitable for mounting in Control / Switchgear panels, machinery consoles.
Glass filled polycarbonate,
flame retardant and drip proof as per UL 94 V-O.
Glass
Black
Vertical
Swivel screws.
Stackable in a single cutout
≤ 40 mm
Hexagon studs, M4 screws and wire clamps E3 (DIN 46282)
Frequency & Phase difference 6 VA Max IP 52 case IP 00 for terminals

660 V

35-70 Hz

+/-9Hz

300 V CAT III

2kV

Pow Enc (IEC 529) Insulation class Insulation voltage Proof voltage Frequency range Pull in / drop out Freq. Installation catogory (IEC1010) insulation resistance

Reference conditions

Ambient temperature Input Voltage Rated frequency

 $23^{\circ}C \pm 3^{\circ}C$ Rated voltage ± 2% 50 Hz± 0.1 %

> 50 Mohm at 500 V d.c.

group A according to VDE 0110

Environmental Conditions

Climatic suitability	Climate category II as per IS : 1248 (climatic class 3 according to VDE / VDI 3540)
Operating temperature Storage temperature Relative humidity	-10+ 55 ⁰ C -20+ 65 ⁰ C ≤ 75 % annual average
Shock resistance	non - condensing 15g, 11ms
	5,
Vibration resistance	10-150-10 Hz / 0.15 mm /
	5 Cycles / 10 octave per minute.

Options

Case Front facia Colour of bezel Colour of LED s Dial Special markings

Antiglare glass Red, Yellow, Blue, White. Orange, Yellow

Numbering / Lettering.


Safety Precautions

- · Instruments with damaged bezels or window glasses must be disconnected from mains.
- · Adequate safety clearance must be maintained to control panel fasteners and to sheet metal housing, if non-insulated connector wires are used.
- · Bezels and window glasses should be replaced under Voltage -free conditions.

Applicable Standards

Nominal case and cutout dimensions fo indicating measuring instruments	or : IS 2419 DIN 43700
Connections and Terminal markings fo panel meters	r: IS 1248 DIN 43807
Terminal bolts / leads.	: DIN 46200/46282
Clamp straps for connections	: DIN 46282
Safety requirements and protective- measures for Electrical indicating- instruments and their accessories.	IS 9249 - 1979 : DIN 40050 / 8-70, VDE 0110/ 11-72 VDE 0410/ 10-76
Performance specification for direct acting indicating analogue electrical measuring instrument and their accessories	IEC 529 , IEC 1010 : IS 1248-1983 IEC 51/DIN EN 6005
Environmental conditions	: IS 1248 - 1983 IS: 9000
Front frames for indicating measuring instruments principal dimensions	VDE / VDI 3540 : DIN 43718
UL Combustibility Class	: UL 94 V-0
Technical conditions of delivery for electrical instruments	: DIN 43701
Mechanical Strength (Free fall test, Vibration test)	: IS 1248/IEC51 IEC1010, IS 9000-1979 VDE 0411 part 1

Connections




TYPE	TERMINAL	
BUS	1-3	1-2
GEN	4-6	4-5
	440V	380V
SQ-96	240V	220V
	480V	415V
	110V	100V
	127V	120V

051

VDE 0411,part 1 Sec 43/44

Dimensions



Dimensions		SQ 96
(in	mm)	
Bezel	а	p 96
Case	b	p 90
Depth	С	106
	d	p 91.5
	е	5.5
Cutout	size	p 92 ^{+0.8}
Weight	(Approx)	0.60Kg.

Ordering Information

Type SQ	Electronic Sychroscope
Front dimention 96	96 mm x 96 mm
Rated voltages	Refer to selection table inside
Front facia	Normal glass
	Antiglare glass *3
Colour of bezel	Black *1 Red,Blue,Yellow,White *3
Position of use	Vertical (0-360 °)
Dial	Additional lettering on request ^{*3} Additional numbering on request ^{*3}
Logo	RISHABH ^{*1} ,for Indian Sales. C.G ^{*1} ,for export through Crompton Greaves I.D. Others ^{*3}

*1 standard

*3 Please clearly add the desired specifications while ordering

Ordering example

SQ 96, rated voltage AC 230 V.

Specifications are subject to change without notice(11/11)

RISHABH INSTRUMENTS PVT.LTD. F-31, MIDC, Satpur, Nashik-422 007, India. Tel.: +91 253 2202160, 2202202 Fax : +91 253 2351064 E-mail : marketing@rishabh.co.in www.rishabh.co.in



www.rishabh.co.in